

# Installing guide for the manure flap in a Premiumfloor slat Typ sow 500 x 600

Testing the position of the manure flap.



Mark the section to saw out.



Saw out the recess with the jigsaw.



## Installing guide for the manure flap in a Premiumfloor slat Typ sow 500 x 600

Install manure flap.



View from underneath.



Press the manure flap against the slat and fix it with 4 Spax bolts 3,5x20 mm.

